Penkhull Service Station Silver Service Schedule

12,000 Miles / 12 Months

LIGHTS & ELECTRICAL SYSTEM

- Check operation of exterior lights
- Check operation of instrument warning lamps
- Check horn
- Check rear reflectors
- Check illumination of dash and heater control lamps
- Check battery condition and connections

INTERNAL/VISION

- Check windscreen wiper and washer condition and operation
- Top up windscreen washer reservoir with additive if required
- Check door/bonnet lock operation and lubricate locks, hinges and catches
- Check/advise pollen filter condition, replace if necessary*
- Check air conditioning system/temperature if applicable

ENGINE

- Drain engine oil and refill*
- Replace oil filter
- Check/advise general oil leaks
- Check/advise coolant level and antifreeze strength
- Check coolant hoses for leaks and condition (inc. header tank)
- Check timing belt replacement interval & report if due according to mileage/age
- Replace air filter
- Top up antifreeze if required
- Check condition and tension of auxiliary drive belts (excl. timing belt)
- Check/clean HT leads and components (if fitted)
- Visual check of fuel system (incl. tank and cap)

BRAKES

- Check brake servo operation
- Check/advise brake fluid level and boiling point
- Top up brake fluid if required
- Visual check of brake pads for water or damage
- Visual check of brake callipers for leaks and security
- Visual check of brake discs, shoes and cylinders for wear or damage
- Visual check of brake pipes and hoses
- Check operation of handbrake
- Check security of handbrake linkages and travel and adjust if required

STEERING/SUSPENSION

- Check condition of road springs
- Check power steering fluid reservoir
- Check steering/suspension components for wear and corrosion
- Check steering rack gaiters condition
- Check shock absorber condition and mounting, report any leaks
- Check wheel bearings for excessive play or noise

DRIVE SYSTEM

- Check/adjust clutch operation
- Check for transmission oil leaks
- Check condition of clutch cable (where visible)
- Check drive shaft gaiters for security and report any leaks
- Check gear box fluid level manual/automatic differential (if applicable)

EXHAUST

Check/advise condition of exhaust and mountings

TYRES/WHEELS

- Check tyre condition and tread depth (inc. spare)
- Check/adjust tyre pressure (inc. spare)
- Check wheel nut torque to manufacturer's specification

FINAL CHECKS

- Reset vehicle service light, where applicable
- Carry out engine management system scan
- Stamp service book

*Additional charges will apply should the vehicle require a pollen filter, special or synthetic oils, platinum or multi-electrode spark plugs.

